

## Sound Gasket

### Supplemental Installation Guide

### **Snipped Inside/Outside Corners:**

### Step 1:

Snip the small return leg at top/back just under the bubble gasket. Do not snip through the bubble gasket.

### Step 2:

Snip 1/8" on the bottom of the Sound Gasket.

### Step 3:

Lightly score the foam tapes with utility knife to keep them from ripping when bent. Do not cut all the way through the tapes.


### Step 4:

Bend Sound Gasket to meet the inside or outside corner and fasten into place with the foam tape.

### Step 1:




Step 3:



Step 2:



Step 4:



# Snipped Horizontal to Vertical Joint:


### Step 1:

Measure horizontal leg to length and snip off a flat 45° triangular section of the product.

### Step 2:

Repeat with the vertical leg, and on install, ensure there are no gaps where the legs meet.

Step 1:



Step 2:





# Sound Gasket Supplemental Installation Guide

# Mitered Horizontal to Vertical Joint:


### Step 1:

Measure top leg to length. Lay product flat on miter saw and make appropriate 45° cut, ensuring product is oriented properly.

#### Step 2:

Repeat with vertical leg, and on install, ensure there are no gaps where the legs meet.

Step 1:



Step 2:

